


1 Select Wearing Style




1 Choose headset wearing style, using guide to assemble.



Over the ear OR Over the head

2 Charge Headset


1 Plug one end of power supply into power jack on back of the base and other end into working power outlet.




2 To charge, dock headset in base for minimum of 20 minutes.




3 Connect TTU – Headset port to base with supplied cable




- 4** While wearing headset tap call control button. Carry on conversation (talk and listen) with outside. End conversation by pressing the call control button again.




CALL CONTROL BUTTON



Trouble shooting Tip: If you cannot hear the outside, make sure that the slide switch (A-G) is set to D . Earpiece and mic volume should be set to 3

 Avoid touching the contacts at the rear of the unit unnecessarily. If operation is interrupted by a static event, power-cycle the product to restore normal functions.

System Features



1 Volume/Mute button

Increase volume Press up*

Decrease volume Press down*

*If headset worn on the left side, up and down positions are reversed.

Mute Press in (base LED solid red)

2 Call Control Button

Answer/end call Tap

3 Narrowband/Wideband Audio Switch

Black Narrowband Audio



Yellow Wideband Audio (desk phone must be capable of wideband audio)

NOTE Talk time will be reduced when operating in wideband mode.

4 Auto Answer Switch

Black (off) Tap call control button to place or answer call

Gray (on) Lift headset from base to place or answer call



norcon communications inc.
510 Burnside Avenue
Inwood, LI, NY 11096